

ASSEMBLY INSTRUCTIONS DECK STRIPE INFLATABLE OUTDOOR CHAIR

ITEM NO: AMFU104





FABRIC COVER x 1




PVC INNER x 1






INFLATE THE PVC INNER 90%. SEAL THE VALVE.

STEP 2




PUT THE COVER FABRIC ON.

STEP 3



CLOSE THE ZIPPER.

FINAL




INFLATE:



PULL VALVE CAP TO OPEN.

INSERT PUMP HOSE OR NOZZLE







REPLACE CAP SECURELY

DEFLATE:



PULL OUT VALVE CAP.

PULL INFLATION VALVE HOUSING TO RELEASE AIR.





REPLACE INFLATION VALVE HOUSING AND CAP SECURELY

VINYL PLASTIC REPAIR KIT INSTRUCTIONS

- 1) CUT TO REQUIRED SIZE DEPENDING ON HOLE.
- 2) CLEAN DAMAGED SURFACE AND ALLOW TO DRY FOR 10 MINUTES.
- 3) REMOVE VINYL PATCH FROM PAPER BACK
- 4) PRESS PATCH FIRMLY OVER HOLE
- 5) **DO NOT** INFLATE FOR 20 MINUTES

Warning! This is not a toy.

Warning! Children must be supervised by an adult to use the product.

Warning! This is not a floating device.

Warning! Do not use in water.

Max. Load 140kg

Note: PVC inner only to be cleaned using wet cloth (Do not use abrasive materials or chemicals)