


Dual Thickness Speed Slicer

G0000032


Thank you for choosing the SVNA Dual Thickness Speed Slicer. To ensure proper operation and to maintain the lifespan of your device, please read these instructions carefully before use.

PRODUCT OVERVIEW

Adjustable Blade for Thick or Thin Slices: The triangle indicators show which thickness has been selected.



THICK: Insert the blade on the right side to create thick slices (+/- 3mm)



THIN: Insert the blade on the left side to create thin slices (+/-1 mm)

PROTECTIVE HAND GUARD

The hand guard is designed to fit securely on the SVNA Speed Slicer, sliding up and down to protect your hands while slicing. Its spikes hold the food firmly down to the last slice. For vertical items like carrots, cucumbers, and zucchini, open the hand guard for a comfortable grip. The hand guard also doubles as a blade cover for safe storage:

Position the hand guard over the blade, then press the two tabs to lock it onto the Speed Slicer.

To unlock, push the hand guard forward to the end of the slicer.



CARE INSTRUCTIONS

Rinse with warm, soapy water for best results and long-term blade sharpness. Handle with care to avoid sharp blades. Dishwasher safe.

WARNING:

Keep out of reach of children. Blades are sharp. Store responsibly and cut away from hands.

CONTACT

IsAlbi, 87 Chifley Drive, Preston, Victoria 3072

P: +61 (03) 9474 1300

E: enquiries@isalbi.com.au